

Continue





























you the time you will spend getting spare parts and repairing. Suppose the refrigerator fans have ice in or around it. Then, you can defrost manually rather than focus a heat gun on your plastic fan, which can ruin it. Suppose you are moving your refrigerator to another location. Then, you can defrost the entire refrigerator according to your schedule. Suppose there is an ice maker that is frozen in place. Starting the defrost cycle manually may be the best choice. The Samsung Forced Defrost Mode is a standard feature that you would find in all Samsung refrigerators. And it makes use of heaters to melt ice and frost all over the refrigerator. Ice and frost form quickly when the warm air from the surroundings enters the refrigerator's compartment and causes condensation. The ice buildup in the refrigerator impairs the performance of your refrigerator. But with the help of the defrost mode, it can easily melt away without leaving catastrophic damage. Once your refrigerator is in diagnostic mode, you can pick one of the two manual defrost modes. There is the refrigerator defrost (rd) and the full defrost (FD) mode: If your display screen shows you the letter 'rd,' it means that option you are looking at is the refrigerator defrost. And it only has control over the defrost cycle of the refrigerator compartment. It serves a good purpose if your goal is to remove ice from your fresh edibles without limiting the performance of the freezer compartment. Like the name, full defrost is a mode that ensures that every compartment in your refrigerator experiences the defrost cycle. And this includes the refrigerator and freezer. It is a mode that is particularly necessary when moving the location of your refrigerator to a new place. There are several places where you can locate the defrost timer of your refrigerator. For example, you can find it on the lower kick plate, the control panel, or the back wall of the refrigerator. You can identify the defrost timer by the four metallic terminals that extend from its bottom. You can remove it from its location as soon as it is within your reach. If your default timer is having issues or you require a new one, you can get one here on amazon at an affordable price. You can defrost your Samsung refrigerator by switching to the force defrost mode and selecting either the refrigerator defrost (rd) or the full defrost (FD). You now know how to put it on the defrost mode, and the alternative defrosts method you can use. Finally, you now know that Samsung can defrost automatically and the importance of the force defrost in your refrigerator.