

[Click Here](#)



New customers, dont worry about programming your DISH TV remoteit works with your new Hopper DVR receiver right out of the box. If you run into remote control hiccups down the road, follow these steps to reset your DISH remote control and get back to watching TV ASAP. Want to cut down on device clutter? The DISH remote is universal. Use the second set of instructions to program your DISH remote to your TV, streaming box, DVD/Blu-ray player, sound bar, or all the above. How to Reset Your DISH Remote Control In two very specific situations, you can follow these instructions to reset the connection between your remote control and DISH receiver: (a) if the Power and Volume buttons are the only working commands or (b) if you recently got a new receiver. Press the SYS INFO button on the front of your DISH receiver. Press the SAT button on your remote and wait to hear three ascending tones. Press the CANCEL or Back button to return to your DISH programming. If the instructions above dont fix the problem with your remote control, troubleshoot other device connections in your TV setup using the instructions below. You can also call customer service at 1-800-333-3474 open 7 days a week until midnight ET. How to Program Your DISH Remote Control to TVs & More If you have a newer remote Usually models 40.0 or higher and included with Hopper, Joey, and Wally receivers. If your remote has a HOME button, press it twice. If your remote doesnt have a HOME button, press MENU once. Select Settings, then navigate to and select Remote Control. Under DEVICES, select the one you want to pair with your DISH remote control. If you dont see the device you want, make sure its properly connected to your receiver or TV. Select the Pairing Wizard to finish programming your DISH TV remote. The wizard will give you step-by-step instructions right on your TV screen. Test the new connection by giving your newly paired device a few commands. If things dont seem right yet, try pairing again with a different code. Multiple pairing codes might work. If you have an older remote Usually models 32.0 or lower and included with VIP receivers. Point your DISH remote control at the device you want to pair. Press and hold the mode button that corresponds with the device type (TV, DVD, or AUX) until all four mode buttons light up. Then release the button and wait for it to start blinking. Press and release the Power button on your remote. When the blinking changes to a solid light, proceed to the next step. Press the Up arrow on your remote and wait a few seconds. If the device youre pairing turns off, proceed to the next step. If it stays on, continue pressing Up every few seconds until it turns off. When your device turns off, press the pound button (#) to save the pairing. Wait for the mode button you selected to flash three times, and the pairing should be complete. Test the new connection by giving your newly paired device a few commands. If things dont seem right yet, try pairing again or call customer service at 1-800-333-3474, open 7 days a week until midnight ET. Can I Program My DISH Remote without a Code? No, pairing codes are required to program any DISH remote control to work your TV or media player. However, the Pairing Wizard on newer DISH remotes gives you onscreen instructions and partially automates the code-finding process, making it a much smoother experience. To upgrade to a newer DISH remote control or receiver, call DISH customer service at 1-800-333-3474. Havent signed up for DISH yet?Shop plans and call to schedule installation as soon as tomorrow. Share Tags: DISH Hopper, DISH Joey, DISH Voice Remote, DISH Wally By providing your email address, you hereby consent to receiving emails from USDISH.com Reddit and its partners use cookies and similar technologies to provide you with a better experience. By accepting all cookies, you agree to our use of cookies to deliver and maintain our services and site, improve the quality of Reddit, personalize Reddit content and advertising, and measure the effectiveness of advertising. By rejecting non-essential cookies, Reddit may still use certain cookies to ensure the proper functionality of our platform. For more information, please see our Cookie Notice and our Privacy Policy. Not quite sure how to pair your remote and DISH receiver? Its simple when you know the right buttons to press.If you need to replace or upgrade your remote, the remote pairing process is quick. In just a few minutes, youll be watching great programming again through your Hopper, with your working remote in hand.This guide will give you step-by-step instructions to program your remote to your DISH receiver, your TV, and other devices. First, learn how to program a DISH remote. Then, find out how to pair a universal remote with DISH, in case you need one in a pinch.How Do I Program My DISH Remote to My TV Receiver?Lets start with DISH remote controls. The great advantage of a DISH remote control is that it will be compatible with your DISH receiver. DISH remotes are easy to identify because each DISH remote has a DISH logo printed on it.Before you start to program your DISH remote to your TV, youll need to figure out what kind of remote model you have. Many remote models are available, and their setups vary somewhat from one model to the next.Which Remote Do I Have?DISH Network provides aguide for customers to identify all the types of remotes that come with their products. Click on the model that most resembles your remote. Once you know which DISH remote you have, you can follow the next steps.Be aware that DISH remotes vary a little in their layout and capabilities, and not all DISH remotes will be able to do exactly the same things with your Hopper, VIP receiver or smart home devices. If you want to get a new DISH remote, you may not be sure how they differ from each other. In general, the newest remotes will have the most advanced functions.Find the Pairing CodeThe more advanced remotes pair instantly without a code. But if your DISH remote doesnt automatically pair, you can look for the right code in your devices instruction manual. Or, you can navigate to the DISH remote guide page to see if you can find your remote code. (Hint: there are many other remote codes on this page, so the information there may also help you find a non-DISH branded remote.)Once you are on the page, scroll down until you see this screen. Look for the link highlighted below in blue under the VIP Receivers section.When you are on that page, click on the link labeled three-digit remote control code." That link will bring up a widget that will allow you to search your remote code by type, brand, and device. (You cant get there from this page; you have to be on the remote guide page to click the widget.) Once you have found your code, proceed to the next steps.Program Remote to ReceiverOn the front panel of your receiver, youll see a series of buttons. Press the button on the front that says SYSTEM INFO.Now take a look at your remote. Locate the SAT button and press it.Right after you press the SAT button, the SYSTEM INFO screen will pop up. Once this happens, click DONE and youre all set.In case the screen does not clear after the process is done, press the CANCEL or BACK button and repeat the first three steps.Input Pairing CodeNow that your DISH remote is paired, your receiver will prompt you to input the pairing code. Once you enter it, youre good to go.How Do I Pair My DISH Remote to My TV or Another AV Device?Before you start this process, know which receiver you have set up on your TV. Follow the instructions for Hopper receivers or VIP-model receivers below.How to Pair Your Remote Control to TV through Hopper / Joey / Wally ReceiversDepending on your type of remote, press either the HOME button twice or the MENU button twice.Select SETTINGS.Scroll down until you can select REMOTE CONTROL.Arrow to the device code you want and select the one for your TV or other device.Choose the appropriate Pairing Wizard for your device.Follow the prompts on the screen to complete the setup.How to Program Your Dish Remote to TV through VIP ReceiversPoint your remote to the device you want to pair it with. Press and hold the mode button you want to program. Youll see that all the buttons light up.When the buttons light up, enter the three-digit code. See steps 3-6 if you are in the AUX mode, otherwise skip to step 7.If youre programming everything in AUX mode, youll have to press the following number first before entering the appropriate code.0 for a TV (i.e. if the code is 700, youll enter 0700).1 for a DVD player or VCR (if the code is 899, enter 1899).2 for any other device (if the code is 242, enter 2242).Once you have entered the correct code, press the # button.The mode button you selected at the beginning of the process will flash three times.Next, press the POWER button on your DISH remote. If the device turns off, then the process has completed successfully.Do Universal Remotes Work with DISH Network?Many universal remotes will work with DISH Network devices.Anytime you receive a DISH Network receiver, youll also get a DISH remote with it. But, if you prefer to pair other remotes to the receiver, you wont have trouble setting them up as long as they are compatible.Once you pair a universal remote to the receiver, youll have access to the usual functions. Youll be able to turn the TV on and off with the power buttons, control volume buttons, and set up recording settings just like you would with a DISH remote.Check for CompatibilityIf youre replacing an old remote, its important to make sure that your new equipment is compatible with your setup, especially if you are trying to use a universal remote. Make sure that any universal remote you purchase is rated for infrared (IR) frequency of 57 kHz.This guideline wont apply to customers setting up brand new DISH equipment, as you will get a compatible DISH remote with your new receiver.How to Program a Universal Remote to Your DISH Network ReceiverUniversal remotes vary, so its a good idea to read the directions for your universal remote to find more specifics on how to pair it with devices. However, below is a general procedure that will work for many universal remotes to pair to a receiver.Locate the SAT button on the front of your remote. Press and hold it for a few seconds until you see the other mode buttons light up.Once other buttons start flashing, press the 3-digit remote code: 000. This is your pairing code.Once you punch in the 3-digit code, press the POWER button and see if your receiver turns off.If your receiver turns off, everything is programmed correctly. Simply press the POWER button again to turn the TV back on.How to Reset Your DISH Remote ControlThe easiest way to do this is to unpair and pair the remote as a way to reset it. This process only takes two simple steps.On the front panel of your receiver, press the SYS INFO button.Once you press the SYS INFO button, use the arrows to select UNPAIR.This will unpair your remote from your device. Wait a few minutes and link to help you find your code, as listed in the Find the Pairing Code section of this guide.)How to Program Remote Models 40.0, 50.0, 52.0, and 54.0 Without a CodeLocate the HOME button on your DISH remote and press it twice.If your remote does not have a HOME button, press the MENU button twice.Once you do this, a screen will pop up. Go to SETTINGS and select REMOTE CONTROL on the display.Now youll see devices on the screen. Select the correct device that you want to pair your DISH remote to.From the options on the menu displayed, select PAIRING WIZARD.Once you do this, different brands will pop up on the screen. Select the correct brand of the device you want to connect to your DISH remote.Because you dont have a code, the pairing wizard will prompt you to try a series of different codes to see which one works.You will need to press the up directional button for the volume or power to test the first code. If this one doesnt work, try the next code. Keep going until the pairing wizard finds the right code.Once the pairing is successful, select FINISH on the screen.Programming your DISH remote to a receiver shouldnt give you a headache. But if you ever run into problems during the setup, you can always reach out to DISH and have them help you over the phone.Remember, whether you have a DISH remote or a universal remote control, theres always a way to complete the setup successfully. Follow the steps in this article and youll be using your remote in no time.FAQs: Troubleshooting When You Pair Your Remote and DISH ReceiverWhy isnt my remote working with DISH receiver or TV?When a remote stops working, the most common problem is dead batteries. So before you get frustrated, put in a spare set of batteries to see if thats your only issue.Why wont my remote change my TV volume?If your remote is working otherwise but wont change your TV volume, you probably need to pair it with your TV.How do I use voice control on my DISH remote?If youre new to voice control, its easy to use! Just press and hold the MICROPHONE button while you speak a simple command. For example, you might say "Yellowstone" to find your favorite show, or Go to channel 241."Why did my remote make my screen black, blue, or snowy?The most common reason why your screen wont cooperate is that you have accidentally pressed the wrong input button on your remote. You can set your remote in LIMITED MODE to keep you from accidentally changing inputs.How can I find my lost remote control?DISH devices like the Hopper and Joey have a "Locate Remote" button on the front. If you cant find your remote, press this button and the remote will begin to beep to lead you to it. Related Posts Whether youre just getting started with your new DISH receiver, youve lost your old remote in the black hole underneath your couch, or you just want an additional control for your TV, youll need to pair the device to your receiver before you can use it. Thankfully, this user-friendly process is easy to do, and most remotes connect with the press of only a few buttonsjust use our guide below to get started.Step 1: Check for CompatibilityIf youre replacing an old remote or getting an extra one, its important to find a replacement compatible with your DISH receiver. Of course, if youre setting up a brand new remote and receiver, youve already got a compatible controller.Certified DISH RemotesThe surest way to ensure compatibility is by using a certified DISH remote. These remotes have the DISH logo along the bottom and often automatically pair with your receiver. In some cases, your replacement remote may have different buttons than the original, which can limit its usability. Dont hesitate to contact DISH directly to purchase the right remote for your receiver.Universal and Learning RemotesIf youre looking to replace a DISH remote quickly and easily, a traditional universal remote can work well. Learning remotes, though, take universality one step further by offering programmable buttons so you can sync up all your most-used buttons just the way you want them. DISH Network receivers utilize an infrared (IR) frequency of 57 kHz, which is on the higher end of power output for IR remotes. Whether you choose a universal or learning remote control, make sure the device is rated for that output. Step 2: Find the Pairing CodeWhile some modern remotes pair instantly with the push of a special scanning button, most controllers require a simple input code for the connection to occur successfully. To pair your remote, look in the devices instruction manual for the pairing code that works with your receiver. You can also find your remote in DISHs pairing how-to library.Step 3: Input the Pairing CodeOnce youve found the directions for your specific remote model, the how-to instructions on DISHs website tell you to press a series of two or three buttons on your remote while the TV is on. This will then prompt your receiver to ask for the input code. Once youve entered that code, the remote is ready to go.Pairing Learning RemotesLearning and universal remotes are a bit more complex. Most can learn from your old remote (if you still have it) by reading its IR signal and copying the signal to one of the buttons on the new device. Follow the manufacturers guidelines carefully and you should have your new remote set up in no time.If youd like to preserve your remote and avoid pairing new ones too often, try to keep your current controller gunk-free with an alcohol wipe or cleaning cloth and remove the batteries before you store the remote for long periods of time. Once your remote is paired, youre all set to explore everything DISH has to offer! From managing your channels to enhancing your viewing experience, having the right package makes all the difference. Visit our Dish Packages page to find the perfect plan for your entertainment needs and discover even more ways to enjoy DISH Network. Share By providing your email address, you hereby consent to receiving emails from USDISH.com

Dish hopper remote pair to tv. Dish hopper pairing. Dish hopper pair remote.